

# How to re-fill your Nescafé® Alegria A510

**NESCAFÉ**  
*Alegria*




## Traditional fill with A510 canisters



Canisters will no longer be available after 26 September 2017

## Non-traditional fill using Nescafé® Gold Blend®

1.



Remove the rubber sleeve


2.

Re-fill with Nescafé® Gold Blend®



Re-attach rubber sleeve and plastic cap

3.



click!

Re-insert coffee container into your machine, and your machine is now ready to serve coffee

